



Gebrauchshinweise

34117 Tropf-Stopp Becher (mit Dekor) 34121 Tropf-Stopp Becher

Für Babys ab 6 Monaten.
Das Mundstück ist nur für die BABY-NOVA Tropf-Stopp Becher geeignet.

Zur Sicherheit Ihres Kindes **ACHTUNG!**

Dieses Produkt darf nur unter Aufsicht von Erwachsenen verwendet werden.
Andauerndes und längeres Saugen von Flüssigkeiten verursacht Karies.
Vor dem Füttern immer die Temperatur prüfen.
Alle nicht verwendeten Einzelteile müssen außerhalb der Reichweite von Kindern aufbewahrt werden.

Reinigung:

Vor der ersten Benutzung, sowie vor und nach jedem weiteren Gebrauch, alle Einzelteile getrennt voneinander gründlich unter fließendem, heißen Wasser mit einem milden Spülmittel reinigen. Dies dient der Sicherung der Hygiene.
Verwenden Sie keine aggressiven Reiniger oder harte Schwämme (Topfreiniger). Die Plastikoberfläche kann dadurch zerkratzen. Nicht im Dampfsterilisator desinfizieren. Nicht über die angegebene Dauer in Desinfektionsmittel (Sterisationslösung) legen. Materialschäden können die Folge sein. Plastikteile nicht auskochen. Silikonteile können ausgekocht werden. Alle Komponenten des Bechers können auch im oberen Korb im Geschirrspüler (max. 65°C) gereinigt werden.

Gebrauchshinweise:

Vor jedem Gebrauch alle Einzelteile überprüfen. Beim ersten Anzeichen von Schäden oder Schwachstellen bitte sofort austauschen. Bei beschädigten Trinkschlitzen ist die Auslaufsicherheit nicht mehr gewährleistet. Den Becher und das Mundstück nicht direktem Sonnenlicht oder Wärme aussetzen. Materialschäden können die Folge sein.

Den Becher stets nur zu $\frac{3}{4}$ mit Flüssigkeit füllen. Getränke nur im offenen Becher in der Mikrowelle erhitzen (nicht empfohlen bei dekorierten Bechern – Dekoration verliert den Glanz). Das Getränk anschließend gut umrühren, um eine gleichmäßige Wärmeverteilung zu bekommen. Es besteht sonst Verbrühungsgefahr.

Durch ungleichmäßiges Erhitzen besteht Verbrühungsgefahr beim Trinken. Den Becher nicht zum Füttern und Lagern von heißen Nahrungsmitteln (über 40°C) verwenden.

Nicht für kohlenensäurehaltige Getränke geeignet, da die Auslaufsicherheit dadurch nicht mehr gewährleistet ist.

Längerer Kontakt mit Flüssigkeiten verursacht Karies.

Herumlaufen während des Trinkens kann zu Verletzungen führen.

Der Silikon-Trinkschnabel ist tropffrei. Es besteht aber die Möglichkeit, dass nach dem Trinken wenige Tropfen im Silikon-Trinkschnabel verbleiben. Durch starkes Schütteln könnte diese Menge austreten.

Die Schlitze im Silikon-Trinkschnabel nicht vergrößern, da diese sonst ihre Auslaufsicherheit verlieren.

Dieser Artikel entspricht der EN 14350.

Bitte Produkt und Gebrauchshinweise aufbewahren.
Für den Reklamationsfall: Herstelleradresse und Artikelnummer aufbewahren.

Using Instructions

34117 Non-Spill Cup (with decoration) 34121 Non-Spill Cup

For babies from 6 months of age.
The mouthpiece only fit the BABY-NOVA Non-Spill Cups.

For your child's safety and health WARNING!

Always use this product with adult supervision.
Never use feeding teats as a soother.
Continuous and prolonged sucking of fluids will cause tooth decay.
Always check food temperature before feeding.
Keep all components not in use out of the reach of children.

Cleaning:

Before first use and before and after each subsequent use wash all the individual parts separately and thoroughly under hot running water with a mild washing-up liquid. This helps to maintain hygiene.

Do not use any aggressive cleaning agents or hard sponges (scourers). This might scratch the plastic surface. Do not disinfect in a steam steriliser. Do not leave in disinfectant (sterilising solution) for longer than recommended. This can lead to damage to the material. Do not boil plastic parts. Silicone parts can be boiled. All of the components of the beaker can also be cleaned in the upper rack of a dishwasher (max. 65°C).

Instructions for use:

Check all individual parts before each use. Please replace parts immediately at the first sign of damage or weakness. If the drinking slit is damaged it is no longer guaranteed to be leakproof. Do not expose the beaker or mouthpiece to direct sunlight or heat. This can lead to damage to the material.

Only ever fill the beaker to $\frac{3}{4}$ full with liquid. Only heat up drinks in the microwave in an open beaker (not recommended for decorated beakers – decoration loses its shine). Then stir the drink well in order to get an even distribution of heat. Otherwise there is a risk of scalding. There is a risk of scalding when drinking if heated unevenly. Do not use the beaker to feed or store hot foods (above 40°C).

Not suitable for fizzy drinks, as it can no longer be guaranteed to be leakproof.

Long periods of contact with liquids can cause tooth decay.

Running around while drinking can lead to injury.

The silicone spout is drip free but a few drops may remain in it after drinking. These may come out if the beaker is shaken hard.

Do not enlarge the slits in the silicone spout, otherwise it will no longer be leakproof.

This article complies with the European Norm EN 14350.

Please keep product and using instructions.

In case of a complaint: keep manufacturer address and article number.